

Simulation report of Lysosome_in_water (1aki.pdb)

Firstly, download the .pdb file from protein data bank (ID: 1AKI). After downloading a file we can visualize the protein structure using VMD, Chimera, PyMOL, etc.

Create one folder (Desktop/Lysosome_in_water)

Open terminal

`cd Desktop`

`cd Lysosome_in_water`

`cd` give direction to the folder or we can go to Lysosome_in_water folder and right click to open terminal.

```
user@gcf51:~$ cd Desktop
user@gcf51:~/Desktop$ cd Lysosome_in_water
user@gcf51:~/Desktop/Lysosome_in_water$
```

`grep -v HOH 1aki.pdb > 1aki_clean.pdb`

The “`grep`” command will remove HOH molecules from the downloaded protein file and save it in a new file i.e, 1AKI_clean.pdb.

`gmh pdb2gmh -f 1aki_clean.pdb -o 1aki_processed.gro -water spc`

The `gmh pdb2gmh` allow us to set a topology. `-f` specify the input file i.e, 1AKI_clean.pdb and `-o` specify the output generated file and process it in .gro format and `-water spc` specify the water model to be use. After running this command, we have to select a force field. In this tutorial we select 15 (OPLS-AA/L all-atom force field) as the force field. Three files were created:

1. .gro: Format structure file which contain all atoms defined within the force field.
2. .itp: Contain information used to restrain the positions of heavy atoms.
3. .top: contain the system topology

Structure of the .top file

```
; Include forcefield parameters
#include "oplsaa.ff/forcefield.itp"

[ moleculetype ]
; Name          nrexcl
Protein_chain_A  3

[ atoms ]
; nr      type  resnr residue  atom  cgnr      charge      mass  typeB      chargeB      massB
; residue  1 LYS rtp LYSH q +2.0
  1  op1s_287    1    LYS      N      1      -0.3      14.0027
  2  op1s_290    1    LYS      H1     1       0.33      1.008
  3  op1s_290    1    LYS      H2     1       0.33      1.008
  .  .  .  .  .  .  .  .  .  .  .  .
```

Figure 1: structure of the topological file

`#include “oplsaa.ff/forcefield.itp”` calls parameter within the OPLSAA force field. `Protein_chain_A` defined molecule name. `[atoms]` defined atom in the protein.

`nr`: Atom number

`type`: Atom type

`resnr`: Amino acid residue number

`residue`: Amino acid residue name

`atom`: Atom name

`chgnr`: charge group number

We defined a box dimension and then filled it with solvent.

`gmh editconf -f 1aki_processed.gro -o 1aki_newbox.gro -c -d 1.0 -bt cubic`

This command defined a box using `editconf`. The function of `-f` and `-o` was already mentioned in the above command. `-c` will keep the protein in the centre of the box. `-d 1.0` is the distance of the protein from the edge box. `-bt` is use to define the box shape (cube). Next, we are ready to fill the solvent.

`gmh solvate -cp laki _processed.gro -cs spc216.gro -o laki _solv.gro -p topol.top`
`solvate` is a tool use to add solvent molecule. Here `-cp` specifies the input coordinate file for solvent. `-cs` specify the configuration of the solvent. `-p` function is to update the file.

`gmh grompp -f ions.mdp -c laki _solv.gro -p topol.top -o ions.tpr`

The `grompp` module can process the coordinate file and topology file to generate an atomic level input i.e. `.tpr` format which is a binary file. This file contains all the parameters for all atoms in the system.

`gmh genion -s ions.tpr -o laki _solv_ions.gro -p topol.top -pname NA -nname CL -neutral`

`genion` is a tool to add ions. It replaced the water molecules with the ions that the user specifies and updates the topological file. `-s` structure the file as an input. Now `-p` will process the topology file; remove the water molecules and ad ions.

Energy minimization

This process helps is stabilizing the structure and resolve steric clashes. Download the file `em.mdp`. This file is use as an input into `grompp` to generate a `.tpr` file.

`gmh grompp -f em.mdp -c laki _solv_ions.gro -p topol.top -o em.tpr`

Here we use the `grompp` module to process the coordinate file and topology file to generate an atomic level input i.e. `.tpr` format.

`gmh mdrun -v -deffnm em`

The flag `-v` will print the progress to the screen at every step. The `-deffnm` define file name of the input. After executing this line, we get the following files:

1. `em.log`: Which is ASCII-text log file of energy minimization process
2. `em.edr`: This is a binary energy file. It contains all the energy terms that the `gromac` collect during the energy minimization.
3. `em.trr`: This is the binary full-precision trajectory file
4. `em.gro`: Energy minimized structure

`gmh energy -f em.edr -o potential.xvg`

We can analyse the `.edr` file using `energy` module. For analysing the potential, we have to select from the prompt "10 0". The data can be plot using `xmgrace` plotting tools.

```
user@gcfs1:~/Desktop/Lysosome_in_water$ gmh energy -f em.edr -o potential.xvg
:~) GROMACS - gmh energy, 2022 (:~)

Executable: /usr/local/gromacs/bin/gmh
Data prefix: /usr/local/gromacs
Working dir: /home/user/Desktop/Lysosome_in_water
Command line:
gmh energy -f em.edr -o potential.xvg

Opened em.edr as single precision energy file

Select the terms you want from the following list by
selecting either (part of) the name or the number or a combination.
End your selection with an empty line or a zero.
-----
1 Bond          2 Angle        3 Proper-Dih.   4 Ryckaert-Bell.
5 Lj-14         6 Coulomb-14   7 Lj-(SR)      8 Coulomb-(SR)
9 Coul.-recip. 10 Potential   11 Pressure    12 Vir-XX
13 Vir-XY       14 Vir-XZ      15 Vir-VX      16 Vir-VY
17 Vir-VZ       18 Vir-ZX      19 Vir-ZY      20 Vir-ZZ
21 Pres-XX      22 Pres-XY     23 Pres-XZ     24 Pres-YX
25 Pres-YY      26 Pres-YZ     27 Pres-ZX     28 Pres-ZY
29 Pres-ZZ      30 #Surf*SurfTen 31 T-rest

10 0

Back Off! I just backed up potential.xvg to ./#potential.xvg.1#
Last energy frame read 455 time 575.000

Statistics over 576 steps [ 0.0000 through 575.0000 ps ], 1 data sets
All statistics are over 456 points (frames)

Energy          Average   Err.Est.    RMSD  Tot-Drift
-----
Potential      -189325    5500    14796.5  -35901.8 (kJ/mol)
```

Figure 1: Finding the potential energy

xmgrace potential.xvg




Figure 2: Potential energy vs. time

Equilibration is conducted in two phases:

1. NVT (constant Number of particles, Volume, and Temperature) which sometimes referred to as “isothermal-isochoric” or “canonical”. This phase helps in stabilizing the temperature of the system. Download the nvt.mdp file

`gmx grompp -f nvt.mdp -c em.gro -r em.gro -p topol.top -o nvt.tpr`

The `grompp` module again is used to process the coordinate file and topology file to generate an atomic level input i.e. .tpr format.

`gmx mdrun -deffnm nvt`

We can analyse the temperature progression using the energy module

`gmx energy -f nvt.edr -o temperature.xvg`

```
user@gcf51:~/Desktop/Lysosome_in_water$ xmgrace temperature.xvg
user@gcf51:~/Desktop/Lysosome_in_water$ gmx energy -f nvt.edr -o temperature.xvg
:~) GROMACS - gmx energy, 2022 (:~)

Executable: /usr/local/gromacs/bin/gmx
Data prefix: /usr/local/gromacs
Working dir: /home/user/Desktop/Lysosome_in_water
Command line:
  gmx energy -f nvt.edr -o temperature.xvg

Opened nvt.edr as single precision energy file

Select the terms you want from the following list by
selecting either (part of) the name or the number or a combination.
End your selection with an empty line or a zero.
-----
 1 Bond                2 Angle                3 Proper-Dih.          4 Ryckaert-Bell.
 5 LJ-14               6 Coulomb-14           7 LJ-(SR)             8 Disper.-corr.
 9 Coulomb-(SR)        10 Coul.-recip.        11 Position-Rest.     12 Potential
13 Kinetic-En.         14 Total-Energy        15 Conserved-En.      16 Temperature
17 Pres.-DC            18 Pressure            19 Constr.-rmsd       20 Vir-XX
21 Vir-XY              22 Vir-XZ              23 Vir-YX              24 Vir-YY
25 Vir-YZ              26 Vir-ZX              27 Vir-ZY              28 Vir-ZZ
29 Pres-XX             30 Pres-XY             31 Pres-XZ             32 Pres-YX
33 Pres-YY             34 Pres-YZ             35 Pres-ZX             36 Pres-ZY
37 Pres-ZZ             38 #Surf*SurfTen       39 T-Protein           40 T-non-Protein
41 Lamb-Protein        42 Lamb-non-Protein

16 0

Back Off! I just backed up temperature.xvg to ./#temperature.xvg.1#
Last energy frame read 100 time 100.000

Statistics over 50001 steps [ 0.0000 through 100.0000 ps ], 1 data sets
All statistics are over 501 points

Energy
-----
Temperature          Average  Err.Est.  RMSD  Tot-Drift
-----
Temperature          299.81   0.099    3.52137 0.594327 (K)

GROMACS reminds you: "Engage" (J.L. Picard)
```

Figure 3: Finding temperature

xmgrace temperature.xvg




Figure 4: Temperature vs. time

2. NPT (constant Number of particles, Pressure, and Temperature)

#npt (Number of particles, Pressure, and Temperature)

gmx grompp -f npt.mdp -c nvt.gro -r nvt.gro -t nvt.cpt -p topol.top -o npt.tpr

gmx mdrun -v -deffnm npt

gmx energy -f npt.edr -o pressure.xvg

```
user@gcf51:~/Desktop/Lysosome_in_water$ gmx energy -f npt.edr -o pressure.xvg
(:) GROMACS - gmx energy, 2022 (-:
Executable: /usr/local/gromacs/bin/gmx
Data prefix: /usr/local/gromacs
Working dir: /home/user/Desktop/Lysosome_in_water
Command line:
gmx energy -f npt.edr -o pressure.xvg

Opened npt.edr as single precision energy file

Select the terms you want from the following list by
selecting either (part of) the name or the number or a combination.
End your selection with an empty line or a zero.
-----
 1 Bond                2 Angle                3 Proper-Dih.          4 Ryckaert-Bell.
 5 LJ-14               6 Coulomb-14          7 LJ-(SR)             8 Disper.-corr.
 9 Coulomb-(SR)       10 Coul.-recip.       11 Position-Rest.     12 Potential
13 Kinetic-En.        14 Total-Energy       15 Conserved-En.      16 Temperature
17 Pres.-DC           18 Pressure           19 Constr.-rmsd       20 Box-X
21 Box-Y              22 Box-Z              23 Volume              24 Density
25 PV                 26 Enthalpy           27 Vir-XX              28 Vir-XY
29 Vir-XZ             30 Vir-YX             31 Vir-YY              32 Vir-YZ
33 Vir-ZX             34 Vir-ZY             35 Vir-ZZ              36 Pres-XX
37 Pres-XY            38 Pres-XZ            39 Pres-VX             40 Pres-VY
41 Pres-VZ            42 Pres-ZX            43 Pres-ZY             44 Pres-ZZ
45 #Surf*SurfTen      46 Box-Vel-XX         47 Box-Vel-VY          48 Box-Vel-ZZ
49 T-Protein          50 T-non-Protein      51 Lamb-Protein        52 Lamb-non-Protein

18 0

Back Off! I just backed up pressure.xvg to ./#pressure.xvg.1#
Last energy frame read 100 time 100.000

Statistics over 50001 steps [ 0.0000 through 100.0000 ps ], 1 data sets
All statistics are over 501 points

Energy                Average  Err.Est.    RMSD  Tot-Drift
-----
Pressure              -132.957    14        340.442  71.8269 (bar)
```

Figure 5: Finding pressure

xmgrace pressure.xvg




Figure 6: Pressure vs. time

gmx energy -f npt.edr -o density.xvg

```
user@cf51: /Desktop/Lysosome_in_water$ gmx energy -f npt.edr -o density.xvg
:-) GROMACS - gmx energy, 2022 (-:
Executable: /usr/local/gromacs/bin/gmx
Data prefix: /usr/local/gromacs
Working dir: /home/user/Desktop/Lysosome_in_water
Command line:
gmx energy -f npt.edr -o density.xvg

Opened npt.edr as single precision energy file

Select the terms you want from the following list by
selecting either (part of) the name or the number or a combination.
End your selection with an empty line or a zero.
-----
1 Bond          2 Angle          3 Proper-Dih.    4 Ryckaert-Bell.
5 LJ-14         6 Coulomb-14     7 LJ (SR)       8 Disper.-corr.
9 Coulomb- (SR) 10 Coul.-reclp.  11 Position-Rest. 12 Potential
13 Kinetic-En.  14 Total-Energy 15 Conserved-En. 16 Temperature
17 Pres.-DC     18 Pressure      19 Constr.-rmsd  20 Box-X
21 Box-Y       22 Box-Z        23 Volume       24 Density
25 pV          26 Enthalpy     27 Vir-XX       28 Vir-XY
29 Vir-XZ      30 Vir-YX       31 Vir-YY       32 Vir-YZ
33 Vir-ZX      34 Vir-ZY       35 Vir-ZZ       36 Pres-XX
37 Pres-XY     38 Pres-XZ      39 Pres-YX      40 Pres-XY
41 Pres-YZ     42 Pres-ZX      43 Pres-ZY      44 Pres-ZZ
45 #Surf*SurfTen 46 Box-Vel-XX   47 Box-Vel-YY   48 Box-Vel-ZZ
49 T-Protein   50 T-non-Protein
51 Lamb-Protein 52 Lamb-non-Protein

24 0

Back Off! I just backed up density.xvg to ./#density.xvg.1#
Last energy frame read 100 time 100.000

Statistics over 50001 steps [ 0.0000 through 100.0000 ps ], 1 data sets
All statistics are over 501 points

Energy          Average      Err.Est.      RMSD Tot-Drift
-----
Density          1045.28        0.67        4.47883    1.88447 (kg/m^3)
```

Figure 7: Finding the density

xmgrace density.xvg




Figure 8: Density vs. time

```

gmx grompp -f md.mdp -c npt.gro -t npt.cpt -p topol.top -o md_0_1.tpr
gmx mdrun -v -deffnm md_0_1
gmx trjconv -s md_0_1.tpr -f md_0_1.xtc -o md_0_1_noPBC.xtc -pbc mol -center
gmx rms -s md_0_1.tpr -f md_0_1_noPBC.xtc -o rmsd.xvg -tu ns
xmgrace rmsd.xvg

```




Figure 9: Root mean square

```

gmx gyrate -s md_0_1.tpr -f md_0_1_noPBC.xtc -o gyrate.xvg
xmgrace gyrate.xvg

```




Figure 10: Radius of Gyration